



Enviroflex® Installation

Step 1

Prepare the Area

The subgrade is prepared per the project requirements. Cut off walls are installed as specified by the engineer.

Step 2

Install the Filter Fabric

Install the appropriate filter fabric as specified on the drawings. If a drainage layer is required, it may be placed concurrently to keep the fabric in place.

Step 3

Place the Block

Blocks are either hand placed or placed with a grappling attachment on an excavator. Please [contact us](#) for rental information.

Step 4

Closure Pour

On terminal ends and areas where Enviroflex® abuts existing structures, concrete is typically poured to finish the area. The concrete should be reinforced, have the same strength as the block, and typically be at least 6 inches wide.

Step 5

Infill

The open cells of Enviroflex® are either backfilled with suitable soil for vegetation, with 3/4 inch diameter crushed stone, or left bare.